

INSTRUCTIONS FOR THUMBPIECE OUTSIDE TRIM

For 9000 Series Rim & Vert Rod Device

	9000TP-00	9000TP-30	9000TP-40	9000TP-05
	<p style="text-align: center;">Lockable Thumbpiece Trim Key locks & Unlocks lever</p>	<p style="text-align: center;">No Cyl, Trim Always Operable</p>	<p style="text-align: center;">Pull When Push bar locked down. Dummy Thumbpiece Trim</p>	<p style="text-align: center;">Key unlock Thumbpiece Key remained on cyl unless locked. Cyl Thumbpiece trim</p>
	13 function Entrance	15 function Passage	10 function Dummy	04 function Storeroom
	<p>ATTACH THE COLLAR AND MORTISE CYLINDER TO THE TRIM PLATE WITH THE MORTISE NUT ATTACH TRIM TO DOOR THRU BOLTING (2) SCREWS TO THE CHASSIS & THE (2) CUP WASHERS AND SCREWS AT THE TOP & BOTTOM TO THE DOOR.</p>	<p>ATTACH TRIM TO DOOR THRU BOLTING THE (2) SCREWS TO THE CHASSIS & (2) CUP WASHERS AND SCREWS AT THE TOP & BOTTOM TO THE DOOR.</p>	<p>ATTACH TRIM TO DOOR THRU BOLTING THE (2) SCREWS TO THE CHASSIS & (2) CUP WASHERS AND SCREWS AT THE TOP & BOTTOM TO THE DOOR.</p>	<p>ATTACH THE COLLAR AND MORTISE CYLINDER TO THE TRIM PLATE WITH THE MORTISE NUT. ATTACH TRIM TO DOOR THRU BOLTING (2) SCREWS TO THE CHASSIS & THE (2) CUP WASHERS AND SCREWS AT THE TOP & BOTTOM TO THE DOOR.</p>