



RF CONNECTORS / SMB

RSBPC01R

DIMENSIONS

RSBJC01R

DIMENSIONS



**SMB PLUG
CRIMP
RIGHT ANGLE**



**SMB JACK
CRIMP
RIGHT ANGLE**

RSBPC01

DIMENSIONS

RSBJC01

DIMENSIONS



**SMB PLUG
CRIMP
STRAIGHT**



**SMB JACK
CRIMP
STRAIGHT**

RSBPS01R

DIMENSIONS

RSBJCB01

DIMENSIONS



**SMB PLUG
SOLDER
RIGHT ANGLE**



**SMB JACK CRIMP
BULKHEAD
STRAIGHT**

RSBPS01

DIMENSIONS

RSBJB01

DIMENSIONS




**SMB PLUG
SOLDER
STRAIGHT**

**SMB JACK RECEPT
BULKHEAD
STRAIGHT**

RF CONNECTORS / SMB

RSBPM01R


DIMENSIONS



SMB PLUG
P.C.B. MOUNT
RIGHT ANGLE

RSBJSB01


DIMENSIONS



SMB JACK SOLDER
BULKHEAD
STRAIGHT

RSBPM01


DIMENSIONS



SMB PLUG
P.C.B. MOUNT
STRAIGHT

RSBJM01R


DIMENSIONS



SMB JACK
P.C.B. MOUNT
RIGHT ANGLE

RSBJP01


DIMENSIONS



SMB JACK
PANEL MOUNT
STRAIGHT

RSBJMB01R



DIMENSIONS



SMB JACK (BLH)
P.C.B. MOUNT
RIGHT ANGLE

RSBJM01


DIMENSIONS



SMB JACK
P.C.B. MOUNT
STRAIGHT

RSBJE01

DIMENSIONS



SMB JACK
END LAUNCH
SMT