The installation instruction of W212 Daytime running light:

The following parts are included in the kit of W212 daytime running light:





Picture 3

Picture 2

- a. To remove the fog lamp and DRL with net support from the bumper.
- b. To assemble (1)Daytime running light and (2)Daylight net support together then install back onto the bumper.
- c. To cover the (3)Chrome molding onto (1)Daytime running light.

To connect electric power and light control system (picture 4)

- d. Use (4)Cable A to connect (1)Daytime running light and plug to the original DRL power socket to get the power.
- e. Two functions for DRL light control system: While the head light is off, the DRL should be 100% lighted on. And while the head light is lighted on, you have two choices for the DRL 100% lighted on or 50% lighted on. If you decide the DRL will be 100% lighted on, you have to use (7)Cable D to connect the wire labeled 100% lighted bulb sign of (5)Cable B and if you want the DRL 50% lighted on, you have to use (7)Cable D to connect the wire labeled 50% lighted bulb sign of (5)Cable B then to connect (7)Cable D to the position light.